SCAN THE **QR CODE** TO WATCH VIDEO GUIDES AT OUR YOUTUBE CHANNEL.

@mihuitoys @MIHUI

Model Number: M1020 | 5369666021 V01

MIHUI

Quick Start Guide

E-Pet Machine

6+

CAUTION!

- As the product is a wireless device using electronic waves please do not connect device to App when in hospitals or on air-crafts.
- Please do not use this product if you have a pacemaker as it contains electronic components, speakers, magnets etc.
- Misuse of batteries could result in heating, rupture, combustion, or leakage. If you use rechargeable batteries please use only the appropriate nickel-hydrogen rechargeable batteries, and be sure to observe the instructions regarding how to recharge.
- Stop use if the product or the battery becomes wet. This may cause a short-circuit.Do not place in water or fire, disassemble, or solder.
- Should liquid leaking from a battery come in contact with the eye, rinse immediately with a large amount of water and consult a physician. Should the liquid come in contact with the skin or clothing, wash with water.
- The batteries should be replaced by an adult.
- Keep battery away from children. Battery may be harmful if swallowed.
- Only use batteries of the same or equivalent type as indicated. Batteries must be inserted with the correct polarity. Do not short-circuit the supply terminals. Do not attempt to recharge non-rechargeable batteries. Rechargeable batteries must be charged under adult supervision. Do not mix alkaline, standard or rechargeable batteries, or different type of batteries. Do not mix new and used batteries. Remove batteries when not in use or discharge. Supervise children if they are replacing batteries themselves to ensure these guidelines are followed. Store unused batteries in their packaging and away from metal objects which can cause a short-circuit.

PRECAUTION FOR USE

- No guarantees are provided regarding lost data.
- Do not place in water or operate with wet hands. This may cause the product to break. Avoid use or storage in high humidity.
- This product is composed of precise electronic parts. Do not drop, get wet, soil, or disassemble. Avoid use or storage in high or low temperatures.
- Battery life time will vary depending on the type of batteries using.
- Recommend to use alkaline batteries.
- By using brand new alkaline batteries, device can stay around 20 days with around 30 min. usage per day.
- Press reset button in case of malfunction.
- Clock accuracy: 10 seconds per day.
- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THE PRODUCT



INSERT BATTERIES

Requires 3 AAA batteries. Alkaline batteries recommended. Adult assembly required.



Slide open the battery compartment door.

Correctly insert 3 AAA batteries and close the compartment door.

BASIC OPERATION



Press any button to turn on the device and start raising your virtual pet right away.